

FasTrack

VISION MATTE APPLICATION

When using Vision Matte to coat a new rubber floor, you can always expect to double your coverage on the second and third coats. The first coat tends to get sucked into the pores of the rubber.

Our recommendation for applying the Vision Matte over our Fastrack is to use a rotary buffer fitted with a soft nylon brush. This will allow the sealer to be pushed into the pores and also speeds the drying time. The buffer helps to get an even coat across the floor.

Before sealing the Fastrack it is always best to clean the surface thoroughly with a rotary buffer to clean away any construction debris and minimize any shading as a result of the manufacturing process. A soft nylon brush should be used for this process.

In cases where more extreme cleaning is needed due to large amounts of soil or shade variance, we recommend using a more aggressive pad such as a 3M blue, brown or even black pad. It is best to reserve the more aggressive pads for extreme cases and then follow up with a sealer. Keep in mind that when aggressive pads are used where the installation has high and low spots, you might see some dark and light spots on the rubber surface as a direct result of the uneven surface. A coat of sealer afterward will blend these areas in nicely for a better visual appearance.

If you have any questions, feel free to contact us.

Centaur
Floor Systems

135 Chapala Street • Santa Barbara, CA 93101
800-536-9007 • (805) 957-0182 • Fax 805-957-0125
www.centaurfloors.com