

NOTICE TO INSTALLERS

(MUST BE READ PRIOR TO INSTALLATION)

(These site instructions are in conjunction with published Manufacturer's Installation Procedure Manual)

Receipt of Materials on Site

- a. Installation site must be dry, clean, dust free and temperature control, between 15 C degrees (60 F) and 30 C degrees (85 F), and relative humidity of 65% or less during entire installation. This must be maintained at a minimum of 48 hours prior to and 72 hours following installation.
- b. On arrival of **Rubber Flooring** at the installation site, all materials must be placed inside room where installation is to occur, a minimum of 48 hours prior to installation. (NOTE: In excess heat or cold weather situations, more time may be required.)
- c. No other trades may work on or near the floor during installation or cure period.

Sub-Floors

- a. All sub-floors must be smooth, even, clean and dry prior to installation of **Rubber Flooring**.
- b. Report any sub-floor deficiencies to General Contractor or owner/agent for resolution **prior** to installation of **Rubber Flooring**.

Material Installation

- a. Follow Industry Standard procedures to lay out **Rubber Flooring** in workspace.
- b. Spread out **Rubber Flooring** prior to installation to inspect for any defects or damages. (*Contact Rubber Flooring dealer to advise.*) Cut and trim out any defects or damages where possible.
- c. During installation, spread adhesive evenly and uniformly, as per manufacturer's instructions, and place **Rubber Flooring** onto fresh adhesive.
- d. Use 75 to 100 lb. flooring roller to ensure proper and uniform bonding to adhesive.
- e. Use masking tape across all joints and seams to prevent gaps between rolls/tiles.
- f. To prevent damage, immediately wipe off any excess adhesive from top surface with denatured alcohol.
- g. For **Rolled Rubber Flooring**, lay protective film and place blocks/bricks for weight over all joints/seams to ensure proper bonding to adhesive and prevent "peaks" at joints (leave tape and blocks in place until adhesive is cured – minimum 24 hours.)
- h. Stay off newly installed floor for a minimum of 24 hours.
- i. **Running Track** must be activity free for a minimum of 48 hours.

**WARRANTY IS VOID IF RUBBER FLOORING MATERIAL IS
INSTALLED OVER DEFICIENT SUB-FLOOR OR WITH IDENTIFIED
DAMAGES OR DEFECTS.**